

Failure to Light

a) Determine if the GFCI (Ground Fault Circuit Interrupting) outlet is functioning properly. If one is not available where needed, contact a qualified electrician for proper installation.

b) If the Lights do not illuminate; Press the on/off button located on the remote control. If failure to light persists; inspect the battery compartment on the remote control to ensure that the batteries are in proper alignment or in need of replacement. (CR2025).

c) Inspect the Coaxial Connections; Ensuring that all Male to Female connection points are properly connected, Threaded & tighten securely.

d) This product employs an overload protection fuse within the Male Plug cavity. If needed; Replace with the spare fuses provided with this product. Do NOT replace the original “Fused” plug provided with this product.

NOTE: Before using or reusing this product every season; Always inspect the product carefully. Discard if product has cut, damaged, exposed copper wire or frayed wired insulation or cracks in the LED holders, etc.

NOTE: Do NOT attempt to replace or modify this product in anyway; Not only will this void the manufactures warranty; but can cause serious injury and harm.

NOTE: This is an electrical product – Not a Toy! Do not use this product for other than its recommended intended use.

NOTE: This is a “Seasonal use” product and is NOT intended for permanent installation or “Year-round” usage.